

**1 MATERIAL**

Cover: polyamide based (PA) technopolymer, black colour, matte finish.  
Graphic symbol "double valve".



Threaded connector: acetal based technopolymer (POM), black colour, matte finish.

**3 PACKING RING**

NBR synthetic rubber.

**4 OVERPRESSURE VALVE**

Technopolymer with NBR synthetic rubber O-ring and stainless steel spring.



Set at around 0.350 bar (on request 0.700 bar).

**6 SUCTION VALVE**

Technopolymer sealing disk with NBR synthetic rubber O-ring and stainless steel spring.



Set at around 0.030 bar.

**8 RING-SHAPED AIR FILTER**

"Tech-foam" polyurethane foam mesh (polyester base), air filtration 40 µ.

**9 FOLD-AWAY KEY**

CWL (on page 11) in acetal resin-based (POM) technopolymer, red colour, with stainless steel anti-intrusion-profile insert.



The key avoids the need for a torque limiter and allows the application of the manual screwing and unscrewing torque.



Also available with accessories sold separately.

**11 SQUARE KEY**

CWQ (on page 11) in zinc-plated steel, the key allows the application of very high torques which make it impossible to unscrew by hand due to the intervention of the torque limiter.



Also available with accessories sold separately.

**13 MAXIMUM CONTINUOUS WORKING TEMPERATURE**

100°C.

**14 "VANDAL-PROOF" SAFETY DEVICE (ELESA PATENT)**

The vandal-proof device prevents unscrewing of the cap by unauthorised personnel as it is equipped with a "controlled-torque" torque limiter.

**16 STANDARD EXECUTIONS**

- SFW-VP: with CWL fold-away key.
- SFW-VP-CH: with CWQ square key.

**17 APPLICATIONS**

SFW-VP pressurised caps are suitable for earthworks and agricultural machinery, and in general for machinery that can be left unattended.

**18 FEATURES**

The use of SFW-VP pressurised breather cap which create a pressure plenum chamber right above the oil level within tested limit conditions, in order to avoid any reservoir deformation, offers also other advantages (see example of functioning in the SFW. on page 1176).

**TECHNICAL DATA**

Air flow rate for the different executions of breather caps can be obtained from the diagram on the basis of the difference of air pressure inside and outside the reservoir.

**SPECIAL EXECUTIONS ON REQUEST**

Caps with flat dipstick, flat section phosphatised steel.



ELESA Original design

**"VANDAL-PROOF" SAFETY DEVICE FUNCTIONING**

- Cap screwing.


Take out the key and screw the cap clockwise until the friction-click controlled torque mechanism is engaged so that to guarantee the best sealing of the packing ring. The maximum torque is reached at the first mechanism release (click).

After that, the cap can neither be screwed (to protect the packing ring) nor unscrewed (to protect the cap from any tampering attempt).



WARNING: during screwing the key must not be inserted.

- Cap unscrewing.

Turn the cap clockwise until one of the two resistance points is reached. Only at one of these two positions the key, which couples the cover to the threaded connector, can be completely inserted and the cap can be unscrewed.




SFW.VP pressurised breather cap functioning in a hydraulic circuit



SFW-VP

Code	Description	d	D	L	d2	h	⚖
54961	SFW.80-VP-3/4-F-350mb	G 3/4	80	68	16	15	147
54967	SFW.80-VP-M42x2-F-350mb	M42x2	80	74	32	21	151



SFW-VP-CH

Code	Description	d	D	L	d2	h	⚖
54962	SFW.80-VP-CH 3/4-F-350mb	G 3/4	80	68	16	15	322
54968	SFW.80-VP-CH M42x2-F-350mb	M42x2	80	74	32	21	326