



3.1
3.2
3.3
3.4
3.5
3.6
3.7
3.8
3.9
3.10



b
5
6
8
10

Specification

- Steel
blackened
- RoHS

Information

Screw drivers GN 613.1 are used in the assembly of indexing plungers GN 613 and spring bolts GN 313. This shortens the assembly time and makes it easier to hold the mechanism in place while fixing the lock nut.

The screw driver is inserted in the side between the knob and guide, where it engages the slot in the guide.

see also...

- *Indexing plungers GN 613* → Page 648
- *Spring bolts GN 313* → Page 691

How to order

GN613.1-6

1 b